

Download File PDF Wiring Diagrams Engine Crusader

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa




My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

Crusader Engine Parts
Wiring Harness & Senders
CM305XL/350XL/350HT



Item	Part No.	Description	Item	Part No.	Description
1	748174	Crusader Engine Wiring Harness	22	85142	Cover, Oil Cooler, Booster Mounting
2	794176	Wiring, Switchgear On Coil	23	21411	Brkt, Coil Mounting (1/2")
3	54072	Wiring, Timing Connector	24	85132	Circuit Breaker Assy. (2x Amp)
4	22044	Wiring, On 1/2" Coil Connector	25	22852	Switch, Oil Cooler Alarm
5	8210000	Washer, Flat	26	21588	Switch, Oil Cooler Alarm
6	8210000	Washer, Flat	27	23228	Switch, Water Temp. Alarm
7	8210000	Washer, Flat	28	20512	Tap Plug
8	90506	Clamp, Support, Round (1 1/2")	29	87727	Switch, Oil Pressure Alarm
9	8202000	Brkt, Support, Coil (1 1/2")	30A	700429	Sender, Oil Pressure (DS, VDC)
10	8202000	Brkt, Support, Coil (1 1/2")	30B	700403	Sender, Oil Pressure (DS, VDC)
11	8202000	Brkt, Support, Coil (1 1/2")	30C	22704	Sender, Oil Pressure (DS, VDC)
12	8202000	Brkt, Support, Coil (1 1/2")	31	700427	Sender, Water Temp. (DS, VDC)
13	8202000	Brkt, Support, Coil (1 1/2")	31A	22707	Sender, Water Temp. (DS, VDC)
14	8202000	Brkt, Support, Coil (1 1/2")	31B	22708	Sender, Water Temp. (DS, VDC)
15	8202000	Brkt, Support, Coil (1 1/2")	31C	22709	Sender, Water Temp. (DS, VDC)
16	8202000	Brkt, Support, Coil (1 1/2")	32	21522	Wkt, Switch Terminal
17	8202000	Brkt, Support, Coil (1 1/2")	33	45377	Lockwasher, Terminal
18	8202000	Brkt, Support, Coil (1 1/2")	34	842A	Washer, Switch Terminal
19	8202000	Brkt, Support, Coil (1 1/2")	35	8900200	Washer, Switch Terminal
20	8202000	Brkt, Support, Coil (1 1/2")	37	16245	Wkt, Switch Terminal
21	8202000	Brkt, Support, Coil (1 1/2")			

When ordering please place "CRU" in front of part number

[Download PDF version of :](#)
Wiring Diagrams Engine Crusader